


TONER STORE

Product Quality is Our Prime Directive | Since 1990




MFP M479 SERIES PRINTERS

1. INSERT TONER CARTRIDGE.
2. USED OR COUNTERFEIT INSTALLED WILL APPEAR.
3. PRESS OK CARTRIDGE READY TO PRINT.



1. IF TONER ICON IS PRESSED, BELOW SECONDARY SCREEN WILL APPEAR INDICATING LOW TONER INSTALLED.
2. PRESS OK IN BOTTOM RIGHT CORNER OF SCREEN.
3. MACHINE WILL GO BACK TO "READY" AND WILL PRINT.



Rectangular Snip

PRO M454 SERIES PRINTERS



1. INSERT TONER CARTRIDGE.
2. SCREEN WILL INDICATE "READY" BUT WILL NOT DISPLAY TONER LEVEL.
3. CARTRIDGE READY TO PRINT.